


# Aspen Water Cooler

## Quick Start Guide


ENSURE THE COOLER STANDS UPRIGHT FOR 24 HOURS BEFORE PLUGGING IT IN.

### OPERATION

1. Place the water cooler on a flat level surface in a cool shaded location near a grounded wall outlet. Position water dispenser so that the back of the unit is a minimum of 4 inches/10 cm away from the wall to ensure proper ventilation.
2. Place the water bottle on top of the cooler appropriately.





3. On Hot & Cold models, vent the hot tank by holding the hot faucet open until water flows out.




4. Plug power supply cord into receptacle. Please ensure that cooler is set up so as access to the power outlet and plug is unobstructed. Turn on heater switch.


Note: To provide additional protection from the risk of shock, this unit **MUST** be connected to a ground fault circuit interrupter (GFCI) outlet at all times. Use of an extension cord will void any warranties.



5. **DO NOT** draw water from the cooler for about 30 minutes to let the water cool or heat. Optimum water temperatures will be reached after several hours of operation.



### EXTERNAL PARTS OF THE WATER COOLER



The customer acknowledges that water, like other liquids, can cause damage to surfaces. The customer takes full responsibility for placing the cooler within a residence or business, and acknowledges that failure to address drips, leaks or spillages is at the customer's risk.